

WIPER AND WASHER SYSTEMS

CONTENTS

	page		page
GENERAL INFORMATION		WIPER SWITCH AND WASHER SWITCH	2
INTRODUCTION	1	DIAGNOSIS AND TESTING	
WINDSHIELD WASHER SYSTEM	1	INTERMITTENT WIPE RELAY	6
WINDSHIELD WIPER SYSTEM	1	WASHER SYSTEM	5
DESCRIPTION AND OPERATION		WIPER SWITCH AND WASHER SWITCH	6
CENTRAL TIMER MODULE	3	WIPER SYSTEM	4
INTERMITTENT WIPE RELAY	3	REMOVAL AND INSTALLATION	
WASHER FLUID LEVEL SENSOR	4	INTERMITTENT WIPE RELAY	9
WASHER NOZZLE AND PLUMBING	4	MULTI-FUNCTION SWITCH	9
WASHER PUMP	4	WASHER SYSTEM	10
WASHER RESERVOIR	3	WIPER ARM	7
WIPER ARM AND BLADE	2	WIPER BLADE	7
WIPER LINKAGE AND PIVOT	2	WIPER LINKAGE AND PIVOT	8
WIPER MOTOR	2	WIPER MOTOR	8

GENERAL INFORMATION

INTRODUCTION

Windshield wiper and washer systems are standard factory-installed equipment on this model. Refer to 8W-53 - Wipers in Group 8W - Wiring Diagrams for complete circuit descriptions and diagrams.

WINDSHIELD WIPER SYSTEM

An intermittent windshield wiper system is standard equipment on this model. The intermittent wiper system lets the driver select from either of two wiper speeds, low or high, or the intermittent wipe delay mode. A knob on the end of the multi-function switch stalk is rotated to select the desired wiper speed, or the intermittent wipe delay mode and interval.

On models equipped with a base version of the CTM, the intermittent wipe mode delay times are driver adjustable from about one-half second to about eighteen seconds. On models equipped with a high-line version of the CTM, the intermittent wipe mode delay times are speed sensitive. Above about sixteen kilometers-per-hour (ten miles-per-hour) the delay is driver adjustable from about one-half second to about eighteen seconds. Below about sixteen kilometers-per-hour (ten miles-per-hour) the high-line CTM doubles the delay time, or provides delays of about one second to about thirty-six seconds. The intermittent wipe mode is provided by delay logic and relay con-

trol circuitry contained within the Central Timer Module (CTM), and an intermittent wipe relay.

The windshield wipers will operate only when the ignition switch is in the Accessory or On positions. A fuse located in the junction block protects the circuitry of the windshield wiper system.

Following are general descriptions of the major components in the windshield wiper system. Refer to the owner's manual in the vehicle glove box for more information on the features, use and operation of the windshield wiper system.

WINDSHIELD WASHER SYSTEM

An electrically operated windshield washer system is standard equipment. A knob on the end of the multi-function switch stalk is depressed toward the steering column to activate the washer system. A washer reservoir in the engine compartment holds the washer fluid, which is pressurized by a pump when the windshield washer switch is actuated. The windshield washer pump feeds the pressurized washer fluid through the washer system plumbing to the windshield washer nozzles.

An optional equipment low washer fluid warning lamp in the instrument cluster will warn the driver when the washer fluid level needs to be checked. Refer to Low Washer Fluid Warning Lamp in Group 8E - Instrument Panel Systems for more information on this feature.

The washers will operate only when the ignition switch is in the Accessory or On positions. A fuse

GENERAL INFORMATION (Continued)

located in the junction block protects the circuitry of the washer system.

Following are general descriptions of the major components in the windshield washer system. Refer to the owner's manual in the vehicle glove box for more information on the features, use and operation of the windshield washer system.

DESCRIPTION AND OPERATION

WIPER ARM AND BLADE

All Ram truck models have two 50.8-centimeter (20-inch) windshield wiper blades with non-replaceable rubber elements (squeegees). These wiper blades include an anti-lift feature. The wiper blades and squeegees must be oriented correctly when installed on the wiper arms for the anti-lift feature to be effective. See Wiper Blade in the Removal and Installation section of this group for more information.

Caution should be exercised to protect the rubber squeegees from any petroleum-based cleaners or contaminants, which will rapidly deteriorate the rubber. If the squeegees are damaged, worn, or contaminated, the entire wiper blade assembly must be replaced.

Wiper squeegees exposed to the elements for a long time tend to lose their wiping effectiveness. Periodic cleaning of the squeegees is suggested to remove deposits of salt and road film. The wiper blades, arms, and windshield should be cleaned with a sponge or cloth and windshield washer fluid, a mild detergent, or a non-abrasive cleaner. If the squeegees continue to streak or smear, the wiper blades should be replaced.

The blades are mounted to spring-loaded wiper arms. The spring tension of the wiper arms controls the pressure applied to the blades on the glass. The windshield wiper arms are secured by an integral latch to the two wiper pivots on the cowl plenum cover/grille panel at the base of the windshield.

The wiper arms and blades cannot be adjusted or repaired. If faulty or damaged, they must be replaced.

WIPER LINKAGE AND PIVOT

The wiper linkage and pivot module is secured with four screws through four rubber grommet-type insulators to the cowl plenum panel beneath the cowl plenum cover/grille panel. The wiper motor is secured with screws to the center of the linkage and pivot module bracket, and the wiper pivots are secured to the ends of the module bracket.

The two wiper pivot crank arms and the wiper motor crank arm each have ball studs on their ends. The motor crank arm ball stud is the longer of the

three. Two drive links connect the motor crank arm to the pivot crank arms.

The passenger side drive link has a plastic socket-type bushing on each end. The driver side drive link has a plastic socket-type bushing on one end, and a plastic sleeve-type bushing on the other end. The socket-type bushing on one end of each drive link is snap-fit over the ball stud on the crank arm of its respective pivot. The driver side drive link sleeve-type bushing end is then fit over the motor crank arm ball stud, and the second socket-type bushing of the passenger side drive link is snap-fit over the exposed end of the motor crank arm ball stud.

The wiper linkage, pivots, bushings, mounting bracket, and motor are only serviced as a complete unit. If any part of this assembly is faulty or damaged, the entire wiper module must be replaced.

WIPER MOTOR

The two-speed permanent magnet wiper motor has an integral transmission and park switch. The motor also contains an internal automatic resetting circuit breaker to protect the motor from overloads.

The motor is secured to the wiper linkage and pivot module bracket with three screws. The wiper motor output shaft passes through a hole in the module bracket, where a nut secures the wiper motor crank arm to the motor output shaft.

Wiper speed is controlled by current flow to the proper set of brushes. The wiper motor completes its wipe cycle when the windshield wiper switch on the end of the multi-function switch stalk is turned to the Off position, and parks the blades in the lowest portion of the wipe pattern.

The windshield wiper linkage, pivots, bushings, mounting bracket, and motor are only serviced as a complete unit. If any part of this unit is faulty or damaged, the entire wiper module must be replaced.

WIPER SWITCH AND WASHER SWITCH

The windshield wiper and washer switches are contained in the multi-function switch assembly (Fig. 1). The multi-function switch assembly is secured to the left side of the steering column. A knob on the end of the multi-function switch stalk is rotated to select the desired wiper speed or intermittent wipe delay, or depressed toward the steering column to activate the washer system.

The multi-function switch contains circuitry for the following functions:

- Turn signals
- Hazard warning
- Headlamp beam selection
- Headlamp optical horn
- Windshield wipers
- Windshield washers.

DESCRIPTION AND OPERATION (Continued)

The information contained in this group addresses only the switch functions for the windshield wiper and washer systems. For information relative to the other switch functions, refer to the proper group. However, the multi-function switch cannot be repaired. If any function of the multi-function switch is faulty, or if the switch is damaged, the entire switch assembly must be replaced.




Fig. 1 Multi-Function Switch

CENTRAL TIMER MODULE

Two versions of the Central Timer Module (CTM) are available on this vehicle, a base version and a high-line version. The base version of the CTM is used on base models of the vehicle. It is also sometimes referred to as the Integrated Electronic Module (IEM). The base version of the CTM combines the functions of a chime/buzzer module, an intermittent wipe module, and an ignition lamp time delay relay in a single unit.

The high-line version of the CTM is used on high-line vehicles. The high-line CTM provides all of the functions of the base version CTM, but also is used to control and integrate many of the additional electronic functions and features included on the high-line models. The high-line version of the CTM contains a central processing unit and interfaces with other modules in the vehicle on the Chrysler Collision Detection (CCD) data bus network.

The CCD data bus network allows the sharing of sensor information. This helps to reduce wire harness complexity, reduce internal controller hardware, and reduce component sensor current loads. At the same time, this system provides increased reliability, enhanced diagnostics, and allows the addition of many new feature capabilities.

Both the base and the high-line versions of the CTM support the intermittent wipe and wipe-after-wash features, but only the high-line CTM supports the speed sensitive intermittent wipe. The intermit-

tent wipe relay is one of the outputs that both the base and the high-line versions of the CTM can control. Each CTM is programmed to energize or de-energize the intermittent wipe relay in response to certain inputs from the windshield wiper and washer switches and from the windshield wiper motor park switch.

For the speed sensitive intermittent wipe feature, the high-line CTM also uses vehicle speed messages, which are received on the CCD data bus from the Powertrain Control Module (PCM). Refer to Group 14 - Fuel Systems for more information on the PCM and the PCM inputs.

Both versions of the CTM are mounted under the driver side end of the instrument panel, inboard of the instrument panel steering column opening. Refer to Central Timer Module in the Removal and Installation section of Group 8E - Instrument Panel Systems for the service procedures.

See Wiper System in the Diagnosis and Testing section of this group for diagnosis of the base version of the CTM. For diagnosis of the high-line version of the CTM or the CCD data bus, a DRB scan tool and the proper Diagnostic Procedures manual are recommended. The CTM cannot be repaired and, if faulty or damaged, it must be replaced.

INTERMITTENT WIPE RELAY

The intermittent wipe relay is a International Standards Organization (ISO) micro-relay. The terminal designations and functions are the same as a conventional ISO relay. However, the micro-relay terminal orientation (or footprint) is different, current capacity is lower, and the relay case dimensions are smaller than those of the conventional ISO relay.

The intermittent wipe relay is a electromechanical device that switches battery current to the windshield wiper motor or wiper motor park switch when the relay coil is grounded by the Central Timer Module (CTM) in response to inputs from the windshield wiper (multi-function) switch. See Intermittent Wipe Relay in the Diagnosis and Testing section of this group for more information.

The intermittent wipe relay is located in the Power Distribution Center (PDC), in the engine compartment. Refer to the PDC label for relay identification and location.

The intermittent wipe relay cannot be repaired and, if faulty or damaged, it must be replaced.

WASHER RESERVOIR

The washer fluid reservoir is secured to the left side of the radiator fan shroud in the engine compartment. The washer pump and motor unit has a barbed nipple, which is installed through a rubber grommet seal inserted in a hole near the bottom of

DESCRIPTION AND OPERATION (Continued)

the reservoir. The washer pump is retained by an interference fit between the barbed nipple and the grommet seal, which is a light press fit.

A snap-fit filler cap with a rubber seal and an integral bail strap is fit to the reservoir filler neck. On models so equipped, the reservoir also has a hole provided for a washer fluid level sensor. Refer to Low Washer Fluid Warning Lamp in the Diagnosis and Testing section of Group 8E - Instrument Panel Systems for diagnosis of the sensor.

The washer reservoir, grommet seals and filler cap are each available for service.

WASHER PUMP

The washer pump and motor are mounted near the bottom of the washer reservoir. A barbed nipple on the pump housing passes through a rubber grommet seal installed in a hole near the bottom of the reservoir. The washer pump is retained by an interference fit between the barbed pump nipple and the grommet seal, which is a light press fit.

A permanently lubricated and sealed motor is coupled to a rotor-type pump. Washer fluid is gravity-fed from the reservoir to the pump. When the motor is energized, the pump pressurizes the washer fluid and forces it through the plumbing to the nozzles.

The washer pump and motor unit cannot be repaired. If faulty, the entire washer pump and motor unit must be replaced.

WASHER FLUID LEVEL SENSOR

The washer fluid level sensor is mounted on the inboard side of the reservoir above the washer pump. A barbed nipple on the sensor is press-fit into a rubber grommet seal installed in a hole in the side of the reservoir.

When the fluid level in the reservoir falls below the pivoting float on the sensor, the float changes position and closes the internal switch contacts of the sensor. Refer to Low Washer Fluid Warning Lamp in the Diagnosis and Testing section of Group 8E - Instrument Panel Systems for diagnosis of the low washer fluid warning lamp and circuit, including the sensor.

The washer fluid level sensor cannot be repaired. If faulty or damaged, the sensor unit must be replaced.

WASHER NOZZLE AND PLUMBING

Pressurized washer fluid is fed through a single hose, attached to a barbed nipple on the washer pump. The hose is routed along the left inner fender shield to an in-line fitting near the dash panel.

A second hose is routed from the in-line fitting through a grommet inserted in a hole in the cowl plenum panel to a wye fitting located in the cowl plenum area, beneath the cowl plenum cover/grille

panel. Hoses from the wye fitting in the cowl plenum are routed through clips molded to the underside of the cowl plenum cover/grille panel to the two washer nozzles. The washer nozzles are snap-fit into openings in the cowl plenum cover/grille panel.

The two fluidic washer nozzles are not adjustable. The nozzles and hose fittings cannot be repaired and, if faulty or damaged, they must be replaced.

DIAGNOSIS AND TESTING**WIPER SYSTEM**

If the problem being diagnosed involves only the pulse wipe or wipe-after-wash modes, see Washer System in the Diagnosis and Testing section of this group. For circuit descriptions and diagrams, refer to 8W-53 - Wipers in Group 8W - Wiring Diagrams.

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, REFER TO GROUP 8M - PASSIVE RESTRAINT SYSTEMS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

(1) Check the fuse in the junction block. If OK, go to Step 2. If not OK, repair the shorted circuit or component as required and replace the faulty fuse.

(2) Turn the ignition switch to the On position. Check for battery voltage at the fuse in the junction block. If OK, go to Step 3. If not OK, repair the open circuit to the ignition switch as required.

(3) Turn the ignition switch to the Off position. Disconnect and isolate the battery negative cable. Unplug the multi-function switch wire harness connector. Connect the battery negative cable. Turn the ignition switch to the On position. Check for battery voltage at the fused ignition switch output (run/accessory) circuit cavity of the multi-function switch wire harness connector. If OK, go to Step 4. If not OK, repair the open circuit to the fuse in the junction block as required.

(4) If the problem being diagnosed involves only the intermittent wipe feature, go to Step 5. If the problem being diagnosed involves all wiper modes, or only the Low and/or High speed modes, go to Step 7.

(5) Turn the ignition switch to the Off position. Disconnect and isolate the battery negative cable. Move the Central Timer Module (CTM) from its mounting position far enough so that the CTM wire harness connectors can be accessed. See Central Timer Module in the Removal and Installation section of Group 8E - Instrument Panel Systems for the

DIAGNOSIS AND TESTING (Continued)

procedures. Unplug the 14-way CTM wire harness connector. Check for continuity between the wiper switch mode sense circuit cavities of the multi-function switch wire harness connector and the CTM 14-way wire harness connector. There should be continuity. If OK, go to Step 6. If not OK, repair the open circuit as required.

(6) Check for continuity between the windshield wiper switch signal circuit cavities of the multi-function switch wire harness connector and the CTM 14-way wire harness connector. There should be continuity. If OK, see Intermittent Wipe Relay in the Diagnosis and Testing section of this group. If not OK, repair the open circuit as required.

(7) Check for continuity between the two wiper switch low speed output circuit cavities of the multi-function switch wire harness connector. There should be continuity. If OK, go to Step 8. If not OK, repair the open circuit as required.

(8) Test the wiper switch. See Wiper Switch and Washer Switch in the Diagnosis and Testing section of this group for the procedures. If the switch tests OK, plug in the multi-function switch wire harness connector and go to Step 9. If not OK, replace the faulty switch and test the wiper system operation. If still not OK, go to Step 9.

(9) Turn the ignition switch to the Off position. Disconnect and isolate the battery negative cable. Move the wiper module far enough to access the wiper motor wire harness connector. Measure the resistance between the ground circuit cavity of the wiper motor wire harness connector and a good ground. The meter should read zero ohms. If OK, go to Step 10. If not OK, repair the circuit to ground as required.

(10) Connect the battery negative cable. Turn the ignition switch to the On position. Place the multi-function switch in the positions indicated in the tests below, and check for battery voltage at the wiper motor wire harness connector.

(a) Check for battery voltage at the fused ignition switch output (run/accessory) circuit cavity of the wiper motor wire harness connector with the wiper switch in any position. If OK, go to Step 2. If not OK, repair the open circuit as required.

(b) Check for battery voltage at the wiper switch low speed output circuit cavity of the wiper motor wire harness connector with the wiper switch in the Low position. If OK, go to Step 3. If not OK, repair the open circuit as required.

(c) Check for battery voltage at the wiper switch high speed output circuit cavity of the wiper motor wire harness connector with the wiper switch in the High position. If OK, go to Step 4. If not OK, repair the open circuit as required.

(d) Check for battery voltage at the wiper park switch sense circuit cavity of the wiper motor wire harness connector with the wiper switch in the Low or High position, then move the switch to the Off position. The meter should switch between battery voltage and zero volts while the wipers are cycling. The meter should read battery voltage when the switch is moved to the Off position until the wipers park, and then read a steady zero volts. If not OK, replace the faulty wiper motor.

WASHER SYSTEM

The diagnosis found here addresses an inoperative washer pump or wipe-after-wash feature. If the washer pump operates, but no washer fluid is emitted from the washer nozzles, be certain to check the fluid level in the reservoir. Check for ice or other foreign material in the reservoir, and for pinched, disconnected, broken, or incorrectly routed washer system plumbing. For circuit descriptions and diagrams, refer to 8W-53 - Wipers in Group 8W - Wiring Diagrams.

WARNING: ON VEHICLES EQUIPPED WITH AIR-BAGS, REFER TO GROUP 8M - PASSIVE RESTRAINT SYSTEMS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIR-BAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

(1) Turn the ignition switch to the On position. Turn the wiper switch to the Low or High speed position. Check whether the wipers operate. If OK, go to Step 2. If not OK, see Wiper System in the Diagnosis and Testing section of this group.

(2) Turn the wiper switch to the Off position. Depress the washer switch. The washer pump should operate and the wipers should operate for as long as the washer switch is depressed. The wipers should continue to operate for about three sweep cycles after the switch is released before they park. If the wipers are OK, but the washers are not, go to Step 3. If the washers are OK, but the wipers are not, go to Step 5.

(3) Turn the ignition switch to the Off position. Disconnect and isolate the battery negative cable. Unplug the washer pump wire harness connector. Measure the resistance between the ground circuit cavity of the washer pump wire harness connector and a good ground. The meter should read zero ohms. If OK, go to Step 4. If not OK, repair the circuit to ground as required.

(4) Connect the battery negative cable. Turn the ignition switch to the On position. With the washer switch depressed, measure the voltage at the washer

DIAGNOSIS AND TESTING (Continued)

switch output circuit cavity of the washer pump wire harness connector. The meter should read battery voltage. If OK, replace the faulty pump. If not OK, repair the open circuit as required.

(5) Turn the ignition switch to the Off position. Disconnect and isolate the battery negative cable. Move the Central Timer Module (CTM) from its mounting position far enough so that the CTM wire harness connectors can be accessed. See Central Timer Module in the Removal and Installation section of Group 8E - Instrument Panel Systems for the procedures. Unplug the 14-way wire harness connector from the CTM. Connect the battery negative cable. Turn the ignition switch to the On position. With the washer switch depressed, check for battery voltage at the washer switch sense circuit cavity of the 14-way CTM wire harness connector. If OK, see Intermittent Wipe Relay in the Diagnosis and Testing section of this group. If not OK, repair the open circuit as required.

WIPER SWITCH AND WASHER SWITCH

See Wiper System and/or Washer System in the Diagnosis and Testing section of this group before testing the multi-function switch. For circuit descriptions and diagrams, refer to 8W-53 - Wipers in Group 8W - Wiring Diagrams.

WARNING: ON VEHICLES EQUIPPED WITH AN AIRBAG, REFER TO GROUP 8M - PASSIVE RESTRAINT SYSTEMS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

(1) Disconnect and isolate the battery negative cable.

(2) Unplug the multi-function switch wire harness connector from the multi-function switch.


(3) Using an ohmmeter, perform the switch continuity checks at the switch terminals as shown in the Multi-Function Switch Continuity chart (Fig. 2).

(4) If the switch fails any of the continuity checks, replace the faulty switch. If the switch is OK, repair the wiper system and/or washer system wire harness circuits as required.

INTERMITTENT WIPE RELAY

For circuit descriptions and diagrams, refer to 8W-53 - Wipers in Group 8W - Wiring Diagrams.

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, REFER TO GROUP 8M - PASSIVE RESTRAINT SYSTEMS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR



MULTIFUNCTION SWITCH PINS

SWITCH POSITION	CONTINUITY BETWEEN
OFF	PIN 6 AND PIN 7
DELAY	PIN 8 AND PIN 9 PIN 2 AND PIN 4 PIN 1 AND PIN 2 PIN 1 AND PIN 4
LOW	PIN 4 AND PIN 6
HIGH	PIN 4 AND PIN 5
WASH	PIN 3 AND PIN 4
*RESISTANCE AT MAXIMUM DELAY POSITION SHOULD BE BETWEEN 270,000 OHMS AND 330,000 OHMS. *RESISTANCE AT MINIMUM DELAY POSITION SHOULD BE ZERO WITH OHMMETER SET ON HIGH OHM SCALE.	

918J-4

Fig. 2 Multi-Function Switch Continuity

INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

RELAY TEST

The intermittent wipe relay (Fig. 3) is located in the Power Distribution Center (PDC) in the engine compartment. Refer to the PDC label for intermittent wipe relay identification and location.

Remove the intermittent wipe relay from the PDC as described in the Removal and Installation section of this group to perform the following tests:

(1) A relay in the de-energized position should have continuity between terminals 87A and 30, and no continuity between terminals 87 and 30. If OK, go to Step 2. If not OK, replace the faulty relay.


(2) Resistance between terminals 85 and 86 (electromagnet) should be 75 ± 5 ohms. If OK, go to Step 3. If not OK, replace the faulty relay.

(3) Connect a battery to terminals 85 and 86. There should now be continuity between terminals 30 and 87, and no continuity between terminals 87A and 30. If OK, see Relay Circuit Test in the Diagnosis and Testing section of this group. If not OK, replace the faulty relay.

RELAY CIRCUIT TEST

(1) The relay common feed terminal cavity (30) is connected to the wiper (multi-function) switch. There should be continuity between the cavity for relay terminal 30 and the two fused ignition switch output

DIAGNOSIS AND TESTING (Continued)

**Fig. 3 Intermittent Wipe Relay**

circuit cavities of the multi-function switch wire harness connector at all times. If OK, go to Step 2. If not OK, repair the open circuit(s) to the multi-function switch as required.

(2) The relay normally closed terminal (87A) is connected to terminal 30 in the de-energized position. There should be continuity between the cavity for relay terminal 87A and the wiper park switch sense circuit cavities of the wiper motor wire harness connector and the 14-way Central Timer Module (CTM) wire harness connector at all times. If OK, go to Step 3. If not OK, repair the open circuit(s) to the wiper motor and CTM as required.

(3) The relay normally open terminal (87) is connected to the common feed terminal (30) in the energized position. There should be battery voltage at the cavity for relay terminal 87 with the ignition switch in the On or Accessory positions. If OK, go to Step 4. If not OK, repair the open circuit to the ignition switch as required.

(4) The coil battery terminal (86) is connected to the electromagnet in the relay. There should be battery voltage at the cavity for relay terminal 86 with the ignition switch in the On or Accessory positions. If OK, go to Step 5. If not OK, repair the open circuit to the ignition switch as required.

(5) The coil ground terminal (85) is connected to the electromagnet in the relay. It is grounded by the CTM to energize the relay and cycle the wiper motor. Check for continuity between the cavity for relay terminal 85 and the intermittent wiper relay control circuit cavity of the 14-way CTM wire harness connector. There should be continuity. If OK, replace the faulty base version CTM; or, use a DRB scan tool and the proper Diagnostic Procedures manual for diagnosis of the high-line version CTM. If not OK, repair the open circuit to the CTM as required.

REMOVAL AND INSTALLATION


WIPER BLADE

NOTE: The notched retainer end of the wiper element should always be oriented towards the end of the wiper blade that is nearest to the wiper pivot.

(1) Turn the windshield wiper switch to the On position. By turning the ignition switch to the On and Off positions, cycle the wiper blades to a convenient working location on the windshield.

(2) Lift the wiper arm to raise the wiper blade and element off of the windshield glass.

(3) To remove the wiper blade from the wiper arm, push the release tab under the arm tip and slide the blade away from the tip towards the pivot end of the arm (Fig. 4).

**Fig. 4 Wiper Blade Remove/Install - Typical**

(4) To install the wiper blade on the wiper arm, slide the blade retainer into the U-shaped formation on the tip of the wiper arm until the release tab snaps into its locked position. Be certain that the notched retainer for the wiper element is oriented towards the end of the wiper blade that is nearest to the wiper pivot.

WIPER ARM

CAUTION: The use of a screwdriver or other prying tool to remove a wiper arm may distort it. This distortion could allow the arm to come off of the pivot shaft, regardless of how carefully it is installed.



(1) Open the hood of the vehicle.

(2) Lift the wiper arm to permit the latch to be pulled out to its holding position, then release the arm (Fig. 5). The arm will remain off the windshield with the latch in this position.

(3) Remove the wiper arm from the pivot using a rocking motion.

(4) Install the wiper arm and blade with the wiper motor in the Park position. See the Wiper Arm Installation illustration (Fig. 6).

REMOVAL AND INSTALLATION (Continued)

**Fig. 5 Wiper Arm Remove/Install****Fig. 6 Wiper Arm Installation**

(5) Mount the arms on the pivot shafts so that the tip of the wiper blade is on the upper edge of the lower windshield blackout area ± 22 mm (± 0.86 in.).

(6) Lift the wiper arm away from the windshield slightly to relieve the spring tension on the latch. Push the latch into the locked position and slowly release the arm until the wiper blade rests on the windshield.

(7) Operate the wipers with the windshield glass wet, then turn the wiper switch to the Off position. Check for the correct wiper arm positioning and readjust if required.

WIPER LINKAGE AND PIVOT


The wiper linkage and pivots can only be removed from or installed in the vehicle as a unit with the wiper motor. See Wiper Motor in the Removal and Installation section of this group for the procedures.

WIPER MOTOR


(1) Disconnect and isolate the battery negative cable.

(2) Remove the wiper arms from the wiper pivots. See Wiper Arm in the Removal and Installation section of this group for the procedures.

(3) Remove the weatherstrip along the front edge of the cowl plenum cover/grille panel and the cowl plenum panel (Fig. 7).

**Fig. 7 Cowl Plenum Cover/Grille Panel Weatherstrip**


(4) Remove the plastic screws that secure the cowl plenum cover/grille panel to the studs on the cowl top panel near the base of the windshield (Fig. 8).

**Fig. 8 Cowl Plenum Plastic Screws Remove/Install**

(5) Lift the cowl plenum cover/grille panel from the cowl top far enough to access the windshield washer nozzle plumbing near the left end of the cowl plenum.


(6) Disconnect the windshield washer supply hose at the wye fitting (Fig. 9).

REMOVAL AND INSTALLATION (Continued)

**Fig. 9 Washer Supply Hose Remove/Install**


(7) Remove the cowl plenum cover/grille panel from the vehicle and set it aside.

(8) Remove the four screws that secure the wiper module to the cowl plenum panel (Fig. 10).

**Fig. 10 Wiper Module Remove/Install**

(9) Move the wiper module as required to access the wiper motor wire harness connector.

(10) Unplug the wiper motor wire harness connectors from the wiper motor (Fig. 11).

**Fig. 11 Wiper Motor Wire Harness Connectors**

(11) Remove the wiper module from the cowl plenum.


(12) Reverse the removal procedures to install. Be certain that the washer nozzle hoses are correctly routed and installed in the retainers on the under-

side of the cowl plenum cover/grille panel. Tighten the mounting screws to 8 N·m (72 in. lbs.).

INTERMITTENT WIPE RELAY

(1) Disconnect and isolate the battery negative cable.

(2) Remove the cover from the Power Distribution Center (PDC) (Fig. 12).

**Fig. 12 Power Distribution Center**

(3) Refer to the label on the PDC cover for intermittent wipe relay identification and location.

(4) Unplug the intermittent wipe relay from the PDC.

(5) Install the intermittent wipe relay by aligning the relay terminals with the cavities in the PDC and pushing the relay firmly into place.

(6) Install the PDC cover.

(7) Connect the battery negative cable.

(8) Test the relay operation.

MULTI-FUNCTION SWITCH

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, REFER TO GROUP 8M - PASSIVE RESTRAINT SYSTEMS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

(1) Disconnect and isolate the battery negative cable.

(2) If the vehicle is so equipped, remove the tilt steering column lever.

(3) Remove both the upper and lower shrouds from the steering column (Fig. 13).

(4) Remove the lower fixed column shroud.

REMOVAL AND INSTALLATION (Continued)




Fig. 13 Steering Column Shrouds Remove/Install - Typical

(5) Move the upper fixed column shroud far enough to access the rear of the multi-function switch (Fig. 14).




Fig. 14 Multi-Function Switch Connector - Typical

(6) Remove the tamper proof mounting screws (a Snap On tamper proof torx bit TTXR20B2 or equivalent is required) that secure the multi-function switch to the steering column.

(7) Gently pull the switch away from the steering column far enough to access and remove the multi-function switch wire harness connector screw.

(8) Unplug the wire harness connector from the multi-function switch.

(9) Reverse the removal procedures to install. Tighten the fasteners as follows:

- Multi-function switch wire harness connector screw - 2 N-m (17 in. lbs.)
- Multi-function switch mounting screws - 2 N-m (17 in. lbs.).

WASHER SYSTEM

WASHER RESERVOIR

(1) Disconnect and isolate the battery negative cable.

(2) Drain the engine cooling system and remove the upper hose from the radiator. Refer to Group 7 - Cooling System for the procedures.

(3) Unplug the wire harness connectors from the washer pump and, if the vehicle is so equipped, the washer fluid level sensor.

(4) Remove the washer supply hose from the washer pump and drain the washer fluid from the reservoir into a clean container for reuse.

(5) While pulling the reservoir away from the fan shroud, lift the reservoir upwards far enough to disengage the reservoir mounting tabs from the upper and lower mounting slots in the fan shroud (Fig. 15).




Fig. 15 Washer Reservoir Remove/Install

(6) Remove the reservoir from the engine compartment.

(7) Reverse the removal procedures to install.

WASHER PUMP

(1) Disconnect and isolate the battery negative cable.

(2) Unplug the wire harness connector from the washer pump.

(3) Remove the washer supply hose from the washer pump and drain the washer fluid from the reservoir into a clean container for reuse.

(4) Using a trim stick or another suitable wide flat-bladed tool, gently pry the barbed inlet nipple of the washer pump out of the rubber grommet seal in

REMOVAL AND INSTALLATION (Continued)

the reservoir. Care must be taken not to damage the reservoir.

(5) Remove the rubber grommet seal from the reservoir and discard.

(6) Reverse the removal procedures to install. Always use a new rubber grommet seal on the reservoir.

WASHER FLUID LEVEL SENSOR

(1) Disconnect and isolate the battery negative cable.

(2) Unplug the wire harness connector from the washer pump.

(3) Remove the washer supply hose from the washer pump and drain the washer fluid from the reservoir into a clean container for reuse.

NOTE: The pivoting float of the washer fluid sensor must be in a horizontal position within the reservoir in order to be removed. With the reservoir empty and held in an upright position, the pivoting float will orient itself to the horizontal position when the sensor connector is pointed straight downwards.

(4) Using a trim stick or another suitable wide flat-bladed tool, gently pry the washer fluid level sen-

sor out of the rubber grommet seal. Care must be taken not to damage the reservoir.

(5) Remove the rubber grommet seal from the reservoir and discard.

(6) Reverse the removal procedures to install. Always use a new rubber grommet seal on the reservoir.

WASHER NOZZLE

(1) Remove the cowl plenum cover/grille panel from the cowl top. See Wiper Motor in the Removal and Installation section of this group for the procedures.

(2) From the underside of the cowl plenum cover/grille panel, disconnect the washer hose from the nozzle fitting.

(3) From the underside of the cowl plenum cover/grille panel, compress the retaining tabs of the washer nozzle and push the nozzle out through the top of the panel.

(4) Reverse the removal procedures to install.

